





HOW TO MEASURE A PACKAGE



340 W 200 S SLC, UT 84101 PREPRESS@UPB.SLC.COM
P: 801 363 0093 F: 801 363 9212

1. Measure length first: Open package - the length is the larger of the two dimensions around the open end.
2. Width is the smallest dimension around the open end.
3. Depth is the distance between the two ends.

STE - Same Tuck Ends



Beers Tray



Roll Over Ends

